

BLUE LINE SECURITY

Randy Thompson
9768 FRED DRIVE NORTHGLENN CO 80260-5564 303-324-7870
bluelinerandy@msn.com

SINGLE USER CODE CHANGE

INSTRUCTIONS FOR THE ALARM LOCK CODE PAD LOCKS

THE "AL" IS THE BUTTON IN THE LOWER RIGHT CORNER

ENTERING THE PROGRAM MODE

AL

- (press the AL before the lock relocks)
- (the lock will beep every few seconds to tell you that are in program mode)
- (you will also be able to retract the latch in the program mode)

ADD NEW USER

AL 2 AL (user number) AL (user code) *

- (user codes can be 4 to 6 digits)
- (user number can be from 12 to 290)
- (if the sequence is done properly, you get a green light)
- (you are still in the program mode)

Example user no 12 with an access code of 15964 (* refers to the star button on the code pad)

AL 2 AL 12 AL 15964 *

Example user no 13 with an access code of 65432 (* refers to the star button on the code pad)

AL 2 AL 13 AL 65432 *

DELETE USER

AL 2 AL (user number) *

- (you are still in the program mode)

TO EXIT PROGRAM MODE

HOLD DOWN THE (AL) FOR A FEW SECONDS UNTIL THE LOCK BEEPS

CONFIRMATION

TRY ALL CODES ADDED AND DELETED

IF YOU MIS-ENTER A CODE OR NOTHING HAPPENS, USE THE "AL" BUTTON TO CLEAR